

## Smart car Trouble shooting

Please upload the code "AUTO\_GO.ino" before testing.

**Q:** Nothing happened after the car was switching "on" ?

**A:** 1. Please check if both the leds on L298N module and UNO board are on. If the LED on the L298N module or the UNO board is not on, then it is because the wires are not well connected to the DC connector. Please reconnect them.

2. Please check if the wiring of the L298n module is correct. Please follow the tutorial exactly and make sure that you do the wiring correctly. Or you can also send us some clear wiring pictures and we' ll check for you.

**Q:** The car is not working properly as expected?

**A:** 1. Please check if the wiring of the L298n module is correct.

2. Upload the code "AUTO\_GO" (Using your own code or forgetting to upload the code and jumping to the next step may cause issues)

3. If the car is still not working properly after the above two steps, maybe the UNO board is not well connected with the V5.0 extension board. Please pull the extension board out and plug it in the uno board again to ensure a well connection.

4. Remove the V5.0 extension board and upload again.

Should you have any confuse in these tests, please feel free to tell us. We' ll always help you.